

Cut canopy sides out of 1/16 PLY, and glue to top of fuse. Pointed ends will cone together.

Glue 1/4" top in place, and sand to rounded contour.

You may have to lightly sand top of sides before attaching top.

This is the original canopy for the pre production Banshee.

